

Black Doorsill Guard

XPEL Black Doorsill Guard is made from a rugged 13 mil embossed PVC for maximum durability. This product will hide existing damage, while helping prevent further chipping, scratching and scuffing to the protected surface.

Directions:

- 1. Ensure that the surface is clean and dry. It is preferred to install XPEL Film in the shade and not direct sunlight
- 2. Cut an appropriate size piece of film form the roll using a pair of scissors.
- 3. Remove the product from the package and without removing the liner, test fit the pieces on the vehicle to check for width and length.
- 4. Remove a few inches of liner on one end, carefully line that end up and install it by smoothing the product down with your hand. Press gently at first, then once you have ensured that it is lined up straight push firmly to eliminate any bubbles.
- 5. Slowly remove the rest of the liner while smoothing down the product with your hand.

XPEL Doorsill Guards are designed to withstand years of wear and tear. However, being semi-permanent, it can easily be removed if needed. Please visit www.xpel.com for complete removal instructions.