

#### INSTALLATION TOOL FROM



**Squeegee** - XPEL Recommends - 8" Redline 1/4" Double Bevel Blade (B3712-8D) **Blades** - XPEL Recommends - 6" Heavy Duty Triumph Scraper Blade (B145H - 10 Pack), or 6" Stainless Steel Triumph Scraper Blade (B145HS - Pack Of 25)

Note: Squeegee and blades sold separately.

#### **EZ** PRESSURE FOREARM STRAP -

**Forearm Strap** - Insert forearm strap through the opening on the bottom side of forearm support. (*Strap can be routed from either direction depending on preference.*)

- Insert the end of straps through opening on respective sides of forearm support.



## USING **EZ** PRESSURE AS AN APPLICATION SQUEEGEE

- 1. Loosen the (3) squeegee/blade retaining screws and remove blade holder and store.
- 2. Insert squeegee, center squeegee and tighten retaining screws.



# USING **EZ** PRESSURE AS A SCRAPER ·

- 1. Loosen the (3) squeegee/blade retaining screws and remove blade holder.
- 2. Remove the (2) handle retaining screws and nuts from under the forearm support. Insert the handle into the end of the EZ PRESSURE tool. Secure handle by installing handle retaining screws & nuts, and tighten.





### BLADE INSTALLATION —

- 1. Using your hands or a flathead screw driver, lift edges of blade holder. Unsnap the two halves.
- 2. Align blade as shown and snap the two halves back together.



3. Insert blade holder, center and tighten retaining screws.

